


[Groups Home](#) - [Yahoo!](#) - [Help](#)

Welcome, **antedeluvian2002** (antedeluvian2002 · akagan@weidmuller.ca)

[Start a Group](#) - [My Groups](#) - [Account Info](#) - [Sign Out](#)

accel-protel · Altium PCAD Users

Group Member [[Edit My Membership](#)]



Messages

[Reply](#) | [Forward](#) | [View Source](#) | [Unwrap Lines](#)

[Messages H](#)

[Search Archive](#)

Message 21649 of 21651 | [Previous](#) | [Next](#) [[Up Thread](#)]

[Message Index](#)

Msg #

[Home](#)

► Messages

[Post](#)

[Chat](#)

[Files](#)

[Photos](#)

[Links](#)

[Database](#)

[Polls](#)

[Calendar](#)

[Promote](#)

From: "Steve Ricca" <SRicca@C...>

Date: Thu Dec 12, 2002 10:12 pm

Subject: Degrees symbol °F

I've always used ALT+248 in most fonts.

Alt 230 is micro μ
And Alt 241 is +/- \pm

Steve Ricca
Ricca Engineering
Columbus, Ohio

= Owner

= Moderator

= Online

ADVERTISEMENT

eHealthInsurance

Need affordable health insurance?

INSTANT QUOTE



Message 21649 of 21651 | [Previous](#) | [Next](#) [[Up Thread](#)]

[Message Index](#)

Msg #

[Reply](#) | [Forward](#) | [View Source](#) | [Unwrap Lines](#)

Copyright © 2002 Yahoo! Inc. All rights reserved.
[Privacy Policy](#) - [Terms of Service](#) - [Guidelines](#) - [Help](#)